



### Installing 2Tall Mudflap:

- Remove standard mudflap
- Position and install the 2Tall mudflap using the two standard bolts and washers
- Drill holes into plastic through the 3 holes in the mudflap.
- Place bracket with through holes in line with holes in mudflap. Insert screws provided and use the nut provided to fasten bracket to the mudflap. You can install the nuts for the screws through the air box.

**Note: Keep rear wheel positioned standard or further back than standard. You can also cut standard mudflap shorter to increase life span.**

